



Check the product prior to Installation.
Must be Installed In accordance with the Installation Instructions.
Only fix using approved fixings.

Refer to **www.snapcollars.com.au**
for the range of tested applications and Installation Instructions.



TITLE:

SNAP 100 High-Top
Floor Waste Shower

DWG NO.

H100FWS-RR

A4

SCALE:1:4

DO NOT SCALE DRAWING

WEB