



Check the product prior to Installation.
Must be Installed In accordance with the Installation Instructions.
Only fix using approved fixings.

Refer to **www.snapcollars.com.au**
for the range of tested applications and Installation Instructions.



TITLE:		SNAP 150 High-Top Floor Waste Shower	
DWG NO.		H150FWS-RR	A4
DO NOT SCALE DRAWING		WEB	
		SCALE:1:4	